

# Empowering Active Lifestyles



WHILL

Personal Electric Vehicle

MODEL A | For seniors

## Boundless possibilities.

We set out to redefine personal mobility, to give you the confidence to go anywhere in style and comfort. It's a thrilling ride, one that will surely put a smile on your face.

The Model A makes you feel empowered, and eager to take on every opportunity life offers.

## Drive safely and securely.

No worries about unsecured rolling or tipping, unlike scooters which may tip or become unstable, Model A's low center of gravity and electromagnetic brakes ensure you are safe and secure. Smooth, responsive controls that are simple to learn and use keep you in control at all times. And glowing rear tail lights make sure everyone sees that you are on the move!

Model A's innovative design, moveable arms and electronic sliding seat allow easy access to tables and desks. The seat is positioned at a height that allows it to fit under most tables and desks, and because it slides forward nearly 6", you can pull right up and join the meal or meeting just like everyone else.



## Comfort and convenience in any setting.

The specialized seating system, custom designed contour back support and ergonomic controls make the Model A so comfortable you'll want to spend the whole day using it.



The unique power sliding seat feature positions you at a natural, close position to tables and desks.

Ergonomic, intuitive mouse controller is simple to use for speed and direction control.



## Uniquely versatile electric vehicle.

---

With the Model A you don't have to choose between indoor agility and outdoor capability. Model A's responsive controls, compact frame and tight turning radius make it extremely agile indoors while its 4WD, front Omni-wheels, power and speed enable you to keep pace with even your most active companions.

## Pursue all paths with precision.

---

Because of its compact size, agility and power, the Model A not only fits through standard doors and maneuvers easily around the home, but also is ideal for shopping, dining, and navigating crowded events. With the Model A, there are boundless possibilities. Go ahead, live an active lifestyle!

Not only are the wheels designed for outdoor use, they are also very easy to clean. Simply wipe them with a damp cloth. You'll be ready to explore again in no time.



The patented two front Omni-wheels are engineered to turn on a dime, pivot in any direction, and tackle uneven, difficult terrain with ease.



## Be driven by a friend or family member.

---

Our iPhone app allows a companion to drive the Model A for you, so they can walk and talk next to you while you enjoy the ride.

## Highest product quality backed up with a 5-year parts warranty.

---

Our 5-year parts warranty demonstrates our commitment to providing products with outstanding reliability. Our goal is to exceed your expectations.

# Built to last.

WHILL was founded by engineers from the automotive and medical device industries and quality, simply put, is in their DNA. With an outstanding commitment to service and reliability you can rely on WHILL to provide products that last and service that exceeds your expectations.

	COMPONENT	ADJUSTMENTS/OPTIONS	
	A - SEAT	DEPTH ANGLE HEIGHT	16" - 20" 1° - 10° 20.2" - 22.2"
	B - ARM	LENGTH ANGLE	0 - 3" 45° - 62°
	C - BACK SUPPORT	ANGLE HEIGHT	94° - 100° LOW/MID
	D - FOOTREST	EXTENSION HEIGHT ANGLE	0 - 4" 5" - 8" 0 - 10°
	E - DIRECTIONAL CONTROLLER	LOCATION TYPE	RIGHT OR LEFT ARM MOUSE OR JOYSTICK

### Additional Options: Controllers

The simple, ergonomic controller is responsive and perfectly placed for easy maneuvering. Choose from either of the two styles.



MOUSE

EASY GRIP

### Additional Options: Back Support

Select from one of two back heights, Low or Mid



LOW

MID

## PERFORMANCE SPECIFICATIONS

ITEM	SPECIFICATION	ITEM	SPECIFICATION
Driving Range (full battery charge)	12 miles	Controller	WHILL Control System
Maximum Speed	5.5 MPH	Turning Radius	28"
Speed Settings	High, Mid, Low	Max Obstacle Height	3"
Drive System	4 Wheel Drive	Chair Ground Clearance	3.5"
Incline Capability	10 Degrees	Braking System	Electromagnetic
Seat Slide Range (electric)	5.9"	Max Weight Capacity	220 lb

## DIMENSIONAL SPECIFICATIONS

ITEM	SPECIFICATION	ITEM	SPECIFICATION
Chair Weight	250 lb	Front Wheel Diameter	9.8"
Chair Width	23.6"	Rear Wheel Diameter	12.5"
Chair Length	35" - 39"	Rear Tires	Solid

## OTHER SPECIFICATIONS

ITEM	SPECIFICATION	ITEM	SPECIFICATION
Battery	12V 50Ah (per battery; 2 total batteries)	Operating Conditions	-13°F to 122°F
Charger	6A Charger	Storage Conditions	-40°F to 149°F
		Tail Lamps (2)	Red Lights

The WHILL Model A is not considered a medical device and has not been submitted to the Food and Drug Administration for review or clearance.  
740-01453-MKT-03 12/2016



(844) 699-4455

[www.whill.us](http://www.whill.us)